

Instructions for Use: Whisper UV Air Fan

Brand Name of Product	Whisper UV Air Fan
Generic Name of Product	UV Air Fan
Product Code Number(s)	WS-1L-60-S-MC-SS
Intended Use	To provide continuous high-quality UV air decontamination in any kind of environment.
Range of Applications for Product	For the elimination of viruses, bacteria, and other pathogens.
Key Specifications of Product	<ul style="list-style-type: none"> • 60W high-output lamp, selective emission peak at 253.7 nm • Stainless steel • Germicidal chamber with high reflectivity • Whisper quiet operation • Weight- 8.8 lbs. • External dimensions- 27.16 H x 6.38 L x 5.98 W (in.) • Lamp life (hrs.)- ≤ 18,000 • Horizontal or vertical application on wall • 24 hrs. continuous operation time: in occupied and non-occupied spaces • High-efficiency electronic ballasts • Up to 2,100 (f³/h) air flow disinfection • Protection rating IP20 • Super-compact size fits anywhere • Special honeycomb TiO_x filter with titanium dioxide nanoparticles and silver salts photoactivated to avoid NOCs and VOCs, and increase indoor air quality with each air exchange

Shipping & Storage	
Shipping Conditions & Requirements	N/A
Storage Conditions	N/A
Packaging Contents	N/A
Shelf Life	One-year limited warranty from the date of purchase for all lamps. Five-year warranty: <ul style="list-style-type: none"> • All ballast • Control boxes • Electronic accessories • All enclosures, racks, and bracketry.

Instructions for Using Product	
Description of Use(s)	To provide continuous high quality UV air decontamination.
Preparation for Use	<ul style="list-style-type: none"> • Install the Whisper UV Air Fan on the wall (about 6-feet above ground-level) or ceiling near the center of the desired treatment area. • The air captured and treated by the Whisper UV Air Fan should be able to circulate through the area unhindered.
Diagrams (drawings, pictures)	N/A
Steps for Use of Product	<ol style="list-style-type: none"> 1. To install the Whisper UV Air Fan on the wall, make two holes in the wall by checking the center distance between the mounting holes on the back of the fan. 2. Secure the Whisper UV Air Fan to the wall (wall fasteners not provided).
Interpretation of Test Results	N/A
Contraindications of Test Results	N/A
Documentation	N/A
Special Warnings and Cautions	N/A
Disposal	N/A

Reprocessing Instructions	
Point of Use	N/A
Preparation for Decontamination	N/A

Disassembly Instructions	N/A
Cleaning – Manual	N/A
Cleaning – Automated	N/A
Disinfection	N/A
Drying	N/A
Maintenance, Inspection, and Testing	N/A
Reassembly Instructions	N/A
Packaging	N/A
Sterilization	N/A
Storage	N/A
Additional Information	N/A
Related Healthmark Products	UVC LED Boxes
Other Product Support Documents	PPE Brochure, PPE Price List
Reference Documents	N/A
Customer Service Contact	Healthmark Industries Company, Inc. 18600 Malyn Blvd. Fraser, MI 48026 1-586-774-7600 healthmark@hmark.com hmark.com